## **Relm GMH/DMH Interface**

These instructions are for interfacing the 20-27B to the Relm GMH or Relm DMH radio. The following items are included in the Relm GMH/DMH interface kit:

- 1. Relm GMH/DMH to 20-27B interface cable assembly.
- 2. Instruction sheet.


The following steps outline the procedure for interfacing the Relm GMH/DMH radio to the 20-27B:

- 1. Connect the DB-25 end of the GMH/DMH interface cable to the DB-25 connector on the back of the 20-27B.
- 2. Connect the DB-15HD end of the GMH/DMH interface cable to the DB-15HD connector on the back of the GMH/DMH radio.
- 3. Configure the following jumpers in the 20-27B as indicated:

JP3: Not shortedJP8: Not shorted

- 4. Using the radio programming software, enable the Tone Remote interface item in the Global Parameters/Data section.
- 5. Configure the remaining jumpers based upon system requirements. The audio level adjustments will also need to be checked.

## **Relm GMH/DMH Interface Cable**



## Relm GMH/DMH Interface Cable Kit 106-27RLMGMH

Item	Description	Part No.	Oty.
1	4-40 X 1/2 SCREW	199-4035	2
2	<b>DB25 CONNECTOR MALE</b>	231-0005	1
3	SCREW/CLIP KIT	231-0014	2
4	<b>DB25 COVER ASSEMBLY</b>	231-0015	1
5	DB15HD COVER	231-0073	1
6	DB15HD CONNECTOR	231-0081	1
7	6 CONDUCTOR CABLE	800-1112	1.3'